



# Motor Protection Circuit Breakers and Motor Circuit Protectors

## Accessories

2

Description		Operator Position *			Term. No.	Description	Connection Diagram *	For Use With	Cat. No.
		OFF	ON	Tripped					
 <p><b>Front-Mounted Trip Contact</b></p> <ul style="list-style-type: none"> <li>2-pole</li> <li>Indicates tripping of device</li> <li>No additional space required</li> </ul>	O	X	O	13-14	N.O. Aux		140M-C, D, F; 140U-D (UL489 only in combination with 140M-C-AFC)	140M-C-AFAR10A10	
	O	O	X	27-28	N.O. Trip (Short-Circuit & Overload)			140M-C-AFAR10A01	
	X	O	X	11-12	N.C. Aux				
	O	O	X	27-28	N.O. Trip (Short-Circuit & Overload)				
 <p><b>Right-Side Mounted Trip Contact</b></p> <ul style="list-style-type: none"> <li>2-pole</li> <li>Indicates tripping of motor protection circuit breaker</li> <li>Adds 9 mm to the width of the circuit breaker</li> <li>One only per MPCB</li> <li>A right-side mounted auxiliary contact may be tandem mounted on top of this trip contact</li> </ul>	O	O	X	57-58	N.O. Trip (Short-Circuit & Overload)		140M-C, D, F	140M-C-ASAR10M10	
	O	O	X	67-68	N.O. Trip (Short-Circuit)				
	O	O	X	57-58	N.O. Trip (Short-Circuit & Overload)		140M-C, D, F	140M-C-ASAR10M01	
	X	X	O	65-66	N.C. Trip (Short-Circuit)				
	X	X	O	55-56	N.C. Trip (Short-Circuit & Overload)		140M-C, D, F	140M-C-ASAR01M10	
	O	O	X	67-68	N.O. Trip (Short-Circuit)				
	X	X	O	55-56	N.C. Trip (Short-Circuit & Overload)		140M-C, D, F	140M-C-ASAR01M01	
	X	X	O	65-66	N.C. Trip (Short-Circuit)				
	O	O	X	77-78	N.O. Trip (Short-Circuit)		140M-C, D, F	140M-C-ASAM11	
	X	X	O	65-66	N.C. Trip (Short-Circuit)				

\* X = Contact Closed; O = Contact Open

